

Smart Watch

User Manual

Bluetooth Reloj Inteligente

Manual

Thank you for choosing our sport healthy intelligent Bluetooth watch. You can read this manual and fully understand the use of the device, in fact, with a taste of the functions and simple method of operation.

This equipment is mainly used brand of intelligent machines to be adapted to use, you can synchronize the phone book smart machines and provides a variety of useful features and services to facilitate your work and leisure activities in the smart machine operation. This device has the following features: support for Bluetooth phone, Bluetooth message push (SMS, micro letter, QQ, etc., need Android to install smart machine above the Bluetooth notification APK), Bluetooth music player, calories, pedometer, sleep monitoring, anti-lost, remote camera and so on.

Before you start using this device, the first smartphone to install the "Bluetooth notice" (BTNotification) application (support Android version, Apple does not currently supported) and run, Bluetooth Smart Watch will be able to automatically synchronize with the time and date of smart phones, and the ability to interface display in the "message" and "distal notice"

watch smartphone received notification of each application or send reminders, including SMS alerts, chat tool QQ, micro letters and other messages and reminders.


Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility settings" and then in the option "Bluetooth notification" application needs to choose a good news message push push or require shielding applications. Restart the phone and smart watches, you can use the Bluetooth connection.

"Bluetooth notification" Applications "Bluetooth notice" application in the country can be a two-dimensional code, or visit the following link to download attachments by scanning: <http://pan.baidu.com/s/1hqsuR7A> can also be installed via smartphone "Searching" Bluetooth notice "application and download and install the application treasure.

By registering overseas can log on Google Play, then scan the QR code, or visit the link to download the APK.



<https://play.google.com/store/apps/details?id=com.oionom.btnotification&hl=zh-CN>



- on off button, exit buttons: Press on off, after power in the operating menu short press buttons, refundable clock interface. The clock in the standby screen, press the button lights on and off the backlight.
- touch keys at lower left corner, Menu Enter key: The standby clock interface to access the main menu, as a confirmation key menu operation;
- middle touch key, dial into flip key: The standby clock interface can enter dial interface, menu operation as the next flip key, Bluetooth when playing music and calls can enter volume adjustment;
- lower right corner of the touch keys, return hang up button: standby no effect, as the return menu operation keys, call hang up button.

In addition, the sliding finger touch can achieve the following functions:

- slide your finger around the touch screen: menu page;
- finger tap the touch screen: enter the menu;
- finger down from the top of the screen vertical stroke: Exit menu;

(2) Bluetooth devices to connect, disconnect, and continued even Connection way: watch initiate pairing Bluetooth connectivity information; Two connections: phone pairing information to initiate a Bluetooth connection. After a successful connection of Bluetooth Smart Watch will automatically send a request requires reading smart phone phonebook and call log (involving personal privacy, some intelligent machines do not open this feature) Please confirm the smart phone, or else the watch can not be synchronized to the phone book and call history will affect its normal use.

If the distance between the watch and smart phones more than 10 meters (middle case no obstructions such as walls, or else shortened distance) will be automatically disconnected within five minutes if the disconnect between the two can be connected also to achieve the distance, the watch will automatically and smart phones continued even otherwise need to manually connect continued.

Watches and smart phones are ringing off the connection is successful and prompt.
(3) Features

- Bluetooth** search for Bluetooth devices, connection, disconnection and other operations.
- Dial clock** interface point in the middle of the dial at the bottom of the screen to enter the key or menu option to enter dial dial dial numbers can also be selected via the menu "Call log".
 - * Do not block the speaker or microphone position during a call.
- information can be viewed smartphone received a text message.
- phone book synchronization of the phone book.
- synchronize phone call records of the "missed call" "Dialed" "Received Calls" "all talk" and other 30 records.
- Bluetooth smartphone push notifications can view the QQ, micro letters and other information.
- Bluetooth music can play music on your smartphone via Bluetooth. Some intelligent machines will need to open the music player software to run properly. Bottom of the screen on the player interface points into the middle button to adjust the volume, or directly on the touch screen point of the volume "+" "-" sign to enter the volume control interface that automatically returns after stopping operation, without manually exit.
- remote camera control via Bluetooth smartphone camera to take pictures. Need the phone off the screen and not in the non-locked state, some smart phones are not matched.
- Pedometer** Pedometer designed specifically for those concerned about the health, recommends the use of chest stride proudly state of motion, the magnitude of the normal walking arm, enabling a more accurate count to the number of steps. Top pedometer interface display for time, as the number of steps for the left

window, the top right window distance (meters) below the display of calorie consumption, the middle square button to start stop switch. The upper right corner of pedometer option, you can set parameters pedometer, reset, view records. Pedometer can run in the background.

To avoid false count, taking the initial steps for each user will not show up immediately in the number of steps the window, but steady pace until the count to start after the show, but also the number of the previous steps counted. Number steps pedometer steps number displayed window is automatically cleared once a day, in the middle and then stop start pedometer, steps number continues to accumulate, not cleared. For clearing the "Reset pedometer" by selecting the Options menu.

- altimeter displays the current altitude.
- barometer shows the current ambient air pressure and temperature.
- Anti-lost alarm when between Bluetooth Smart watches and smart phones connected over a certain distance, the watch will sound an alarm.
- power saving mode
- setting the clock, the tone mode, volume, language, display settings, view battery power, as well as Bluetooth settings and restore the factory settings 4 Bluetooth smart watch can connect a standard USB data cable, via computer USB port or a USB charger jack.

Tarjeta de garantía:

Número de documento para tres garantías:
Documento para tres garantías de usuario:

Nombre de usuario	Teléfono de contacto
Dirección de usuario	
Código postal	Fecha de compra
Número de factura	Fecha de lanzamiento
Tienda de compra	Teléfono de tienda
Dirección de tienda	
Código postal	Sello de tienda
Vendedor	

- Notas
1. Primero, por favor llene cuidadosamente este formulario y se necesita el sello de distribuidor.
 2. Segundo, por favor traiga esto junto con la factura de compra para el servicio.
 3. Tercero, por favor, manténgase en contacto con nuestros puntos de servicio, nuestros ingenieros estarán respondiendo preguntas a tiempo para sus soluciones y servicios.



Gracias por elegir nuestro Bluetooth Reloj Inteligente para deporte. Usted puede leer este manual y entender completamente el uso del dispositivo, de hecho para saber las funciones y simple método de operación.

Este dispositivo se utiliza principalmente en los smartphones (teléfonos inteligentes) de marca, se puede sincronizar la guía telefónica de los smartphones y ofrecer una variedad de características y servicios útiles para facilitar su trabajo y actividades de ocio en el funcionamiento de su smartphone. Este dispositivo tiene las siguientes funciones: soportar de Bluetooth, mensaje de Bluetooth (mensajes cortos, WeChat, QQ, etc., se necesita instalar APK notificación de Bluetooth en smartphone de Android), reproductor de música Bluetooth, caloría, podómetro, poligrafía, anti-perdida, cámara a distancia y así sucesivamente.

Antes de usar este dispositivo, en primer lugar, se necesita instalar Aplicación "notificación de Bluetooth" (BTNotification), (apoyar la versión de Android, actualmente no apoyar la versión de Apple) y ejecutar, este Bluetooth Smart Watch puede sincronizar automáticamente con la hora y la fecha de smartphones, y puede recibir notificaciones o recordatorios enviados por cada aplicación de smartphones en la pantalla de interfaz de "mensaje" y "aviso distal" de smartphone, incluyendo recordatorios de mensajes cortos, herramienta de chat QQ, Wechat y otros recordatorios de mensajes.

Se necesita abrir el servicio "notificación de Bluetooth" en "configuración de accesibilidad" de smartphone cuando usted necesita usar el servicio "notificación de Bluetooth" y luego en la opción de aplicación "notificación Bluetooth", se necesita elegir las aplicaciones que se requiere recibir o detener. Reinicie teléfono móvil y smartphone, puede utilizar la conexión Bluetooth.

La aplicación "Notificación Bluetooth" en China, La aplicación "Notificación Bluetooth" se puede descargar por digitalizar código bidimensional o visitar este enlace: <http://pan.baidu.com/s/1hqsuR7A> También se puede descargar e instalar a través de "tesoro de aplicaciones" de smartphone y buscar "Notificación Bluetooth".

En extranjero, en primer lugar, necesitan registrar Google play, luego escanear el código, o visite el enlace <https://play.google.com/store/apps/details?id=c> para descargar el APK.



Nuestra empresa se reserva el derecho que podemos modificar los contenidos de este manual sin previo aviso.



1. Cómo usar y operar.

Use este reloj inteligente Bluetooth en la dirección correcta, el botón de encendido debe estar en el lado derecho del reloj cuando se usa en el lado derecho, tres botones táctiles situados debajo del espejo.

• El botón de ON/OFF, botón de salida: Prena larga botón de ON/OFF; después de la energía en el menú operativo botones de presión corto, interfaz de reloj reembolsable. El reloj en la pantalla de espera, pulse el botón que se ilumina y apaga la luz de fondo.

• El botón táctil a esquina izquierda, el botón de menú / confirmar: Cuando está en espera, La interfaz de reloj puede acceder al menú principal, como una operación de menú de la tecla de confirmación;

• El botón táctil central, Dial clave de entrada / Flip: Cuando está en espera, La interfaz de reloj puede entrar en el dial de la interfaz, la operación del menú depende del botón del Flip, cuando se reproduce música Bluetooth y llamadas pueden entrar en el ajuste del volumen;

• El botón táctil a esquina derecha, botón de Volver/ Colgar: en espera ningún efecto, en la operación como botón de volver, en las llamadas como botón de colgar.

Además, toque un dedo deslizante puede lograr las siguientes funciones:

- deslizar el dedo por la pantalla táctil: página de menú;
- toque la pantalla táctil: entrar en el menú;
- hacia abajo desde la parte superior de la pantalla trazo vertical: Salir del menú;

2. Conectar dispositivo de Bluetooth, desconectar, y conectar de nuevo

Forma de conexión una: Reloj de iniciar el emparejamiento información de conexión:

Forma de conexión dos: Teléfono móvil de iniciar el emparejamiento información de conexión de Bluetooth;

Después de una conexión exitosa, Reloj Inteligente Bluetooth enviará automáticamente una solicitud que requiere la lectura de guía telefónica y los registros de llamadas de smartphone (que implica la intimidad personal, algunos smartphones no abren esta característica) Por favor, confirme su smartphone, o de lo contrario el reloj no se puede sincronizar con la guía telefónica y los registros de llamadas que afectará a su uso normal.

Si la distancia entre el reloj y teléfono inteligente es más de 10 metros (caso medio no hay obstáculos, como paredes, de lo contrario la distancia se reduce en consecuencia) se desconectará automáticamente, si la distancia entre ellos volverá a la conexión que se puede conectar, el reloj puede conectar automáticamente teléfono inteligente, lo contrario, se necesita conectar a mano.

Cuando el reloj y teléfono inteligente conectan correctamente o desconectan, tendrán indicaciones de voz.

3. Características

• **Bluetooth** Las operaciones de búsqueda de Bluetooth, conexión, desconexión y otras operaciones.

• **Marcar** En el medio de interfaz de reloj o la opción de marcar del menú para entrar marcar, también se puede marcar a través del menú "Registro de llamadas".

* No bloquee el altavoz o posición del micrófono durante una llamada.

• **Mensajes** Se puede ver mensajes recibidos por teléfono inteligente.

• **Guía telefónica** Sincronización de la guía telefónica.

• **Registros de llamadas** Sincronizar la "llamada perdida" "marcados", "llamadas recibidas" "todos hablan" y otros cada 30 registros.

• **Notificación de Bluetooth** Puede ver la información de QQ, Wechat y otra información.

La Ventana de podómetro se borra automáticamente una vez al día, si se para en medio de su paseo y luego inicie el número, el número de pasos sigue acumulando, sin borrar. Si se necesita borrar, puede entrar el menú de opción para elegir "Restablecer podómetro".

Alarma anti-perdida Cuando Bluetooth inteligente reloj y teléfono inteligente conectados supera una cierta distancia, el reloj sonará una alarma.

Modo de ahorro de energía

Ajustar Pueden ajustar reloj, modo de tono, volumen, idioma y otros ajustes, compruebe la batería, y la configuración de Bluetooth y restaurar la configuración de fábrica.

4. Este Bluetooth reloj inteligente puede conectar un cable de datos USB estándar, a través del puerto USB de la computadora o de un conector del cargador USB.